









## Notes:

- The Zero Point is the front of the stem at underside of deck at the sheer.
- The (fore-&-aft) centreline is marked c/line.
- Offsets are measured about centreline.
- Heights are measured above or below (marked "-") the dwl.
- Positions are measured forward and aft (marked "-") of the Zero Point.
- Offsets on diagonals are measured along the diagonal.
- Waterlines are marked "wl" followed by their height. Buttock lines are marked "b" followed by their offset.
- 9. Diagonals are marked "d" followed by their height on the centreline and then their angle to it.
- 10. All offsets are to inside ofskin unless otherwise noted.



1/2

**Boat 119** 

Stbd Cockpit Seat Detail

Date 20/05/2000 Plan No. 119/003/09 Issue No. 01 web

© bmarkweb Ltd 2002 All Rights Reserved

All dimensions in millimetres unless noted otherwise