



- General Notes:
1. The Zero point is the intersection of the Datum Water Line (dwl) with the stem face.
 2. Positions are measure fwd and aft (marked "-") of the Zero Point.
 3. Heights are measure above and below (marked "+/-") the dwl.
 4. Offsets are measured each side of the centreline (marked "C/line").
 5. Waterlines are designated "wl" followed by their height.
 6. Buttocks are designated "b" followed by their offset.
 7. Sections are designated "s" followed by their position.
 8. Diagonals are designated "d" followed by their start height on the centreline and their angle to it.
 9. Offsets on diagonals are measured down the angle of the diagonal.
 10. Data is to inside of skin unless noted otherwise.
 11. All dimensions in millimetres unless otherwise noted.

Boat 012 Interior Furniture Layout	Scale	1/10
	Date	14/01/2009
	Plan No.	012/010/10
	Issue No.	01
Drawing Size		915 x 305 - 36" x 12"