



Notes:

1. The Zero Point is the front of the stem at underside of deck at the sheer.
2. The (fore-&-aft) centreline is marked c/line.
3. Offsets are measured about centreline.
4. Heights are measured above or below (marked "-") the dwl.
5. Positions are measured forward and aft (marked "-") of the Zero Point.
6. Offsets on diagonals are measured along the diagonal.
7. Waterlines are marked "wl" followed by their height.
8. Buttock lines are marked "b" followed by their offset.
9. Diagonals are marked "d" followed by their height on the centreline and then their angle to it.
10. All offsets are to inside ofskin unless otherwise noted.

Offsets to give shape of bunk top edges		
Position	Offset of top face at dwl +124	Offset of bottom face at dwl +115
-300	177	173
-990	493	488
-1615	716	711
-2241	863	858

Whisstock
boats and boat plans

support@whisstock.com

Boat 119

Fwd Bunk Bases

© bmarkweb Ltd 2002 All Rights Reserved

Scale	1/10 & 1/2
Date	20/05/2000
Plan No.	119/010/01
Issue No.	01 web
All dimensions in millimetres unless noted otherwise	