



**Notes:**

1. The Zero Point is the front of the stem at underside of deck at the sheer.
2. The (fore-&-aft) centreline is marked c/line.
3. Offsets are measured about centreline.
4. Heights are measured above or below (marked "-") the dwl.
5. Positions are measured forward and aft (marked "-") of the Zero Point.
6. Offsets on diagonals are measured along the diagonal.
7. Waterlines are marked "wl" followed by their height.
8. Buttock lines are marked "b" followed by their offset.
9. Diagonals are marked "d" followed by their height on the centreline and then their angle to it.
10. All offsets are to inside ofskin unless otherwise noted.

 <b>Whisstock</b> boats and boat plans	support@whisstock.com	
	<b>Boat 119</b>	Scale 1/10 & 1/2
<b>Fwd Bunk Fronts</b>	Date 20/05/2000	
	Plan No. 119/010/02	
	Issue No. 01 web	
	All dimensions in millimetres unless noted otherwise	

© bmarkweb Ltd 2002. All Rights Reserved