



- Notes:**
1. The Zero Point is the intersection of the Datum Water Line (dwl) with the stemface.
  2. Positions are measured fwd and aft (marked "-") of the Zero Point.
  3. Heights are measured above and below (marked "-") the dwl.
  4. Offsets are measured each side of the fore-&-aft centreline.
  5. Waterlines are designated "wl" followed by their height.
  6. Buttocks are designated "b" followed by their offset.
  7. Diagonals are designated "d" followed by their start height on the centreline and their angle to it.
  8. Offsets on diagonals are measured down the angle of the diagonal.
  9. Offsets are to inside of skin unless noted otherwise.

- Specific Notes:**
1. "CM" indicates items manufactured/supplied by Classic Marine.
  2. Positions of jib & staysail sheet leads should be ascertained on sail trials - positions shown are for guidance only.

**Whisstock** support@whisstock.com  
boats and boat plans

<b>Boat 119</b> <b>Deck Plan</b>	Scale 1/10 & 1/2
	Date 10/07/2000
	Plan No. 119/012/01
	Issue No. 01 web
All dimensions in millimetres unless noted otherwise	

© bmarkweb Ltd 2002 All Rights Reserved