



<b>Boat 123</b>	Scale 1/10
<b>Longitudinal Structures (Outboard Engine)</b>	Date 18/10/2000
	Plan No. 123/003/01
	Issue No. 01 web
All dimensions in millimetres unless noted otherwise	

© bmarkweb Ltd 2002. All Rights Reserved



Note: Stem face is cleaned off to face offsets after planking is completed.

Offsets for fwd & aft faces of apron, stem and stem face

Note: Apron reaches full siding (190 mm = 95 Offset) at -450 and runs parallel aft to end at -1115.

- Notes:**
1. The Zero Point is the intersection of the dwl with the stem at the forefoot.
  2. The (fore-&-aft) centreline is marked c/line.
  3. Offsets are measured about centreline.
  4. Heights are measured above or below (marked "-") the dwl.
  5. Positions are measured forward and aft (marked "-") of the Zero Point.
  6. Offsets on diagonals are measured along the diagonal.
  7. Waterlines are marked "wl" followed by their height.
  8. Buttock lines are marked "b" followed by their offset.
  9. Diagonals are marked "d" followed by their height on the centreline and then their angle to it.
  10. All offsets are to inside ofskin unless otherwise noted.

