



Note: Styles tenon into top rail. Bottom rails tenon into styles. Door rails and styles are morticed and tenoned together.

Note: Fit Timage 379100c catch at top of doors. Hang doors on 2 off brass butts 38 x 22.



VERTICAL SECTION Scale 1/2

Shape of Bottom Edge		
Position	Height from dwl	
	Inboard face	Outboard face
-2600	55	69
-2900	23	35
-3200	20	30
-3475	38	50



HORIZONTAL SECTIONS Scale 1/2

**General Notes:**

1. The Zero Point is the intersection of the Datum Water Line (dwl) with the stemface.
2. Positions are measured fwd and aft (marked "-") of the Zero Point.
3. Heights are measured above and below (marked "+") the dwl.
4. Offsets are measured each side of the fore-&-aft centreline.
5. Waterlines are designated "w/l" followed by their height.
6. Buttocks are designated "b" followed by their offset.
7. Diagonals are designated "d" followed by their start height on the centreline and their angle to it.
8. Offsets on diagonals are measured down the angle of the diagonal.
9. Offsets are to inside of skin unless noted otherwise.

**Whisstock**  
boats and boat plans

support@whisstock.com

<p><b>Boat 146</b></p> <p><b>WC Locker</b></p>	Scale 1/10 & 1/2
	Date 15/03/2007
	Plan No. 146/010/12
	Issue No. 02 web
All dimensions in millimetres unless noted otherwise	

© bmarkweb Ltd 2007 All Rights Reserved